



Fig 2





Panels can be used for walls and roofs. Pre-engineered wire chases and openings. Standard trusses can be used

Fig 2A




Fig. 3

Fig 4





Fig 5






Fig 6

Sheet rock





Fig 7











Process steps:

1. Solid block of core material
2. Cut outline shape with computer added design
3. Cut shape of supporting members as required using computer added design
4. Cut electrical chases as required
5. Install or applied inside and outside covering as required

Fig 8










Fig 15








Fig 18




Fig 19

30






Fig 20






Fig 21

Adjacent Panel

Fig 20A



20B







Fig. 23



66077" E45E460304





Fig 26



cell 102




Fig 28A









Fig 28B














Fig. 36

FIG 37

